

HYDRO LIFE

THE BACTERIA FIGHTER • THE BACTERIA FIGHTER • THE BACTERIA FIGHTER

MODEL HL-200 EXTERIOR WATER FILTER

NEW INSTALLATION:

1. Your Hydro Life filter comes with a filter cartridge installed. There is no need to unscrew the housing until you are ready to replace the cartridge.
2. This filter is designed to be installed between two hoses. We recommend allowing enough hose length between the water supply and your RV so the filter unit rests on the ground. This will prevent unnecessary strain on connections and allow filter to work at peak efficiency. Ultimately the use of a holder (such as Hydro Life's removable exterior water filter holder) would be ideal.
3. Filter must be installed so that water flows through it in the direction of the arrows imprinted on the filter cap.
4. Install incoming water line to female hose adapter on filter. Turn water on and briefly flush the system. Turn water off. Connect hose from your RV to male hose adapter and turn water supply on.

NEW CARTRIDGE REPLACEMENT:

1. Turn off water supply. Remove hose connection from your RV.
2. Unscrew filter housing. Remove and dispose of used cartridge.
3. Clean inside of housing and cap with mild soap and water, rinse thoroughly.
4. Remove O-ring from housing and carefully wipe clean. Re-coat lightly with petroleum jelly (Vaseline®). This will ease reopening unit next time and provide a tight seal. Place O-ring back into groove on housing making sure it is seated properly.
5. Place new cartridge into housing, large end first. The smaller end should be towards the top cap. Screw housing onto the cap. Hand tighten only. Do not overtighten.
6. Follow steps 3-4 under Installation.

REPLACEMENT CARTRIDGES:

Replace filter cartridge annually to maintain high quality water. This filter should be replaced if undesirable taste or odor appear, or if water flow decreases significantly. Please replace this cartridge with Hydro Life Filter #5, Model C2063.

IMPORTANT:

- Do not allow filter to freeze.
- Replace filter annually to maintain high quality water.
- When winterizing do not allow anti-freeze to flow through filter.
- Do not use where water is microbiologically unsafe or of unknown quality.
- If your RV or watercraft has not been used recently, turn water on and allow it to flow for several minutes to flush the system.

If you should need assistance, please call your RV or marine parts dealer.

